

INVISI·FAST

HIDDEN DECK FASTENER

Spacing Recommendations

Composite Decking Spacing Recommendations

1/8"	3/16"	1/4"
Correct Deck™	Geodeck™	Trex™
Timber-Tech™	Weather Best™	Rhino Deck™
EverGrain Decking™	Fiberon™ Decking	Symmatrix™
Elk Cross Timbers™		Latitudes Composite Decking™
Vekadeck™		ChoiceDek™
Exotics by Monarch™		Veranda™
Procell™		

Natural Wood Spacing Tip

The best practice for natural woods, such as Redwood and Cedar, is to space boards at 1/8" but use the NO-spacer Invisi-Fast fastener. Because the natural woods have much more expansion and contraction, NOT using a mechanical spacer provides more allowance for expansion and contraction without undue stress. The Zero-spacebar Invisi-fast fasteners are designed to provide the optimal performance and beauty for natural wood decks. When installing the NO-Spacebar Invisi-fast fasteners on natural wood decks, use some 1/8" spacebar fasteners or a suitable size nail, to create a temporary space while installing the Invisi-fast fasteners, then remove the temporary spacer.